



Containment Plan for Spills for the Service Technicians

The goal of this plan is to contain the spill to the immediate area around the portable toilet and/or hand washing stations to prevent contamination of production areas.

1. Assess the area. Report to office if there is any damage to property.
2. Use appropriate PPE to protect yourself from the spill.
3. If unit is tipped over, pick unit up and set back on the base. Secure unit. Assess for any damage on the unit and record under drivers notes.
4. Remove any soiled or damage toilet paper and/or paper towels from the unit and place them in the disposal bucket.
5. Remove any soiled or damage hand sanitizer and/or soap refills from the unit and place them in the trash bucket if damaged.
6. Contain any spilled material.
7. Pump out any waste that may still be in the tank(s) and any waste or effected soil present on the ground surrounding the unit.
8. Clean up any waste that may have spilled on the ground and put it in the disposal bucket.
9. Completely clean and sanitizer the unit, inside and outside the unit.
 - a. Spray unit the entire unit with chlorinated water.
 - b. Spray unit with washdown spray
 - c. Scrub unit with brush to remove dirt and waste.
 - d. Wash down the unit with chlorinated water.
 - e. Squeegee excess water off unit.
 - f. Using a clean dry towel, wipe unit dry.
10. Restock the unit with new toilet paper/paper towels.
11. Restock the unit with new hand sanitizer/soap if needed.
12. Write your initials and date on the unit.
13. Spray sanitizing solution around the affected area.
14. Make any notes in the drivers notes, as well as pictures as needed.
15. Double check to make sure all the above has been done before you leave the area.
16. Empty disposal bucket at the waste facility.